

HOW TO USE THE CLEARCLICK VIDEO TO DIGITAL CONVERTER



Plug in and turn on device & VCR/DVD player



1

Connect RCA cable (x2)

Connect the red, white, and yellow RCA cable first into the VCR player's output (middle row) and then into the device



2



Memory/Storage


Insert USB flash drive, SD card, or connect a personal device using HDMI cable

3



VHS or DVD?

Load the VHS tape or DVD disc into the player



4



Press Play on VCR

...and then the red record/stop button on the device to create a new file on your storage media.

5

● REC

FYI:

- You cannot use fast-forward to speed up the process. Each VHS tape/DVD must be allowed to play in real-time to record.
- Each time the process is paused, stopped, fast-forwarded, etc., a new file is created on your flash drive/ SD card, etc.
- You can turn the volume down during the conversion process without it affecting the volume in the recording.